




# ACCESSORIES

## ISW - Inductive Limit Switch

|                                   |               |
|-----------------------------------|---------------|
| ISW M8x1 With<br>M8x1 Connector   | VK5 VH-S/SI   |
|                                   | VK10 VH-S/SI  |
|                                   | VK25 VH-S/SI  |
|                                   | VK50 VH-S/SI  |
|                                   | VK100 VH-S/SI |
|                                   | VK150 VH-S/SI |
|                                   | VK250 VH-S/SI |
|                                   | VK350 VH-S/SI |
| ISW M12x1 With<br>M12x1 Connector | VK5 VH-S/SI   |
|                                   | VK10 VH-S/SI  |
|                                   | VK25 VH-S/SI  |
|                                   | VK50 VH-S/SI  |
|                                   | VK100 VH-S/SI |
|                                   | VK150 VH-S/SI |
|                                   | VK250 VH-S/SI |
|                                   | VK350 VH-S/SI |




M8x1 inductive detector with M8x1 connector




Note: Operation indicator (yellow LED, 4x90°)

Inductive detector M12x1 with connector M12x1



Note: Operation indicator (yellow LED, 4x90°)

Inductive detector M8x1 with connector M12x1 (optional)




Note: Operation indicator (yellow LED, 4x90°)

### Connector specifications

CC Model 3-wire  
PNP-NC input

### Operating diagram



### Input circuit

